


Комплект запасных частей
для ремонта РДГБ-6



Принципиальная схема РДГБ-6



Pos	Обозначение	Наименование детали	Кол.
1	РДГБ-6-05-00СБ	Клапан	1
2	РДГБ-6-13-00СБ	Клапан	1
3	РДГБ-6-14-00СБ	Клапан	1
4	РДГБ-6-01-07	Мембрана	1
5	РДГБ-6-01-10	Кольцо	1
6	РДГБ-6-01-10-01	Кольцо	1
7	РДГБ-6-02-10	Мембрана	1
		Кольца по ГОСТ 100980-80	
10		006-009-19-2-024	3
11		010-013-19-2-024	1
12		014-017-19-2-024	2
13		018-021-19-2-024	1
14		021-024-19-2-024	1
15		029-032-19-2-024	2



Регулятор давления газа
РДГБ-6

